



STATIC COLOUR SETTINGS

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option C--

PRESS ENTER button on rear of light

SELECT colour using UP & DOWN buttons

PRESS ENTER to select and store colour

SOUND ACTIVATED MODE

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option Snd

PRESS ENTER button on rear of light

SELECT Sound program 1-5 using UP & DOWN buttons

PRESS ENTER to select and sound activated setting

BLUETOOTH APP MODE

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option blE

PRESS ENTER button on rear of light

PRESS ENTER to select and Bluetooth APP setting



BRIGHTNESS LEVELS

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option diM

PRESS ENTER button on rear of light

SELECT level using UP & DOWN buttons

PRESS ENTER to select and store brightness setting

AUTO PROGRAMS MODE

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option P-

PRESS ENTER button on rear of light

SELECT Auto program 1-5 using UP & DOWN buttons

PRESS ENTER to select and Auto program setting

DMX CONTROL MODE

PRESS MENU button on rear of light

SELECT UP or DOWN until you see the option 3ch or 7ch

PRESS ENTER button on rear of light

SELECT DMX channel using UP & DOWN buttons

PRESS ENTER to select and DMX setting